

## **INSTRUCTIONS FOR NON-SKID ADDITIVE (POWDER)**

**For use with Quick Glaze, MMA System, K1000, Gel coat or Resin**

1. Mix 32:1 of the powder into the appropriate Basecoat or Gel coat or Resin.
2. Catalyze the coating first then add the powder. Reduce as necessary after the powder is added.

The Quick Glaze system will give the best results, smooth roll out, great adhesion and a durable finish on both Acrylic and Gel coat. Use K1000 with etch on enamel, porcelain and ceramic. When actual Gel coat is used, we recommend clear PVA sprayed over the application to assure a thorough cure. Spray the liquid PVA over the application immediately and apply heat. This will eliminate the tacky finish of the resin.

NOTE THE COATING OR RESIN WORKING TIMES AND CLEANUP RECOMMENDATIONS

**See Non-Skid Surface Application Instructions for complete procedure.**

**FOR ORDERS AND INQUIRIES CONTACT:**

**MULTI-TECH PRODUCTS**

**TOLL FREE 800-218-2066**

**[orders@multitechproducts.com](mailto:orders@multitechproducts.com)**

**[www.multitechproducts.com](http://www.multitechproducts.com)**